

Empowered by Innovation

NEC

Introduction

Connecting the
Headset System

Setting the Controls

Using the Headset
(On Back)



DSX

Wireless Headset Adapter User Guide



A50-016312-001
1093059

Rev 1, February 4, 2009
Printed in U.S.A.

ABOUT THE DSX HEADSET ADAPTER

What it Does

The DSX Headset Adapter allows you to connect a Plantronics Wireless Headset System directly to your DSX telephone's headset jack. The DSX Headset Adapter tightly integrates your headset system with the DSX to provide enhanced wireless mobility and call answering. The Plantronics lifter is not required.

DSX Headset Adapter Compatibility

The DSX Headset Adapter is compatible with all Plantronics Wireless Headset Systems that support a handset lifter, including:

- CS55 Series
- CS70 Series
- Supraplus Wireless Series
- Voyager Series

For more on Plantronics wireless headset solutions, visit: www.plantronics.com

DSX Telephone Compatibility

The DSX Headset Adapter is compatible with the following DSX telephone models (and DSX IP keysets):

- DSX 34-Button Backlit Display Telephone *Series 2* (or higher)
- DSX 34-Button *Full-Duplex* Backlit Super Display Telephone

USING THIS GUIDE

This guide complements the User Guide provided with your Plantronics Wireless Headset System. Be sure to read and follow the information in that guide regarding:

- Charging and positioning your headset.
- Powering up your headset.
- Applicable warnings, safety, and regulatory information.
- Wireless Headset System maintenance and troubleshooting.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This Class B digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

DSX 34-Button Backlit
Display Telephone *Series 2*



DSX Wireless
Headset Adapter



Plantronics Wireless Headset Systems



INSTALLING THE HEADSET ADAPTER

The Auxiliary Connector

The DSX Headset Adapter plugs into the Auxiliary Connector on the bottom of your telephone. When your telephone comes from the factory, the Auxiliary Connector is protected by a plastic cover. You must remove this cover before installing the adapter. If your telephone *does not* have an Auxiliary Connector, it is not compatible with the Headset Adapter.

To remove the Auxiliary Connector Plastic Cover:

1. Turn your telephone over and place it on a smooth, soft surface.
2. Using small diagonal pliers, carefully snip the two tabs that secure the connector cover to the telephone base.
3. Turn the phone over so the cover falls clear.



The Headset Adapter

To install the Headset Adapter:




1. Turn your telephone over and place it on a smooth, soft surface.
2. Line up the connector in the Headset Adapter with the Auxiliary Connector on the telephone.
3. Carefully snap the DSX Headset Adapter into the telephone base.

CONNECTING TO THE HEADSET SYSTEM

Connecting to the Headset System Base



To connect your telephone to the Headset System Base:

1. At right, using the short line cord provided with your Headset System, plug the cord into the telephone's headset jack and the jack on the Headset System base.
2. Then, plug the extension's line cord into the jack on the bottom of the telephone.



3. Above, insert the Headset Adapter plug into the lifter jack on the Headset System base.
4. At right, plug the Headset System power supply into the base and into a handy 110 VAC outlet.


SETTING UP THE HEADSET SYSTEM CONTROLS



The Phone System Configuration Dial

To set the Configuration Dial for DSX compatibility:

1. At left, turn to position 1.



Intellistand™ Enable/Disable

Even though you are not using a Handset Lifter, you should enable Intellistand™.

To enable Intellistand™:

1. Above, set to the bottom position.

The Call Control Buttons

Use these buttons to answer a ringing call or hang up your current call. Not all base units have a Call Control button.


To use the Call Control buttons:

1. At left, tap a Call Control button.
 - See your Plantronics User Guide for more.

Adjusting the Speaking Volume

To adjust the headset speaking volume:

1. Set the Transmit Slide Switch to position **C**.
2. While on a call, adjust the Headset Microphone Volume Control as required.



Adjusting the Listening Volume

To adjust the headset listening volume:

1. Set the Receive Slide Switch to position **2**.
2. While on a call, adjust the Headset Receive Volume Control as required.
 - The volume control on your headset may be different than shown.

To mute the headset microphone:

1. Press and release the Headset Receive Volume Control to mute; Press and release to un-mute.

USING THE HEADSET

Your extension is automatically in the Headset Mode when your headset is removed from its base. There is no need to have a Headset Feature Key or dial **#HS** to turn the Headset Mode on and off.

To place a call when using your headset:

1. Press a line key or **INTERCOM** and dial normally.
2. To hang up, tap your headset Call Control button.
 - Your Ring/Message Lamp lights solid green when you are on a headset call.

To answer a call when using your headset:

1. When you hear ringing (triple beeps) in your headset, tap your headset Call Control button.
 - If your extension has Headset Voice Announce enabled, voice-announced Intercom calls beep and then connect to your headset.
 - If your extension has Headset Voice Announce disabled, you hear three beeps in your headset followed by your caller's voice broadcasting from your telephone speaker. To switch the call to your headset, tap the headset Call Control button.

To convert a headset call to a Handsfree call:

1. Press **SPEAKER**.
 - For Group Listen, press **SPEAKER** again (until it flashes).
 - If you don't tap Call Control to hang up during Handsfree or Group Listen, the call returns to your headset when you press **SPEAKER** to hang up.

To convert a headset call to a Handset call:

1. Lift the handset.
2. Tap Call Control.

Other Feature Interactions

- Pressing **MUTE** while on a call mutes the headset microphone.
- Off-Hook Signaling works normally.
- Paging announcements broadcast through the telephone speaker, not the headset.
- While on a headset call, receive volume control is adjusted locally at the headset only.

A50-016312-001



NEC

NEC Unified Solutions, Inc.
4 Forest Parkway, Shelton, CT 06484
TEL: 203-926-5400 FAX: 203-929-0535
www.necdsx.com

Empowered by Innovation **NEC**